



Electronic Cigarettes

User Manual



Getting Started

Your Suncig e-cigarette comes charged and ready to go. Simply screw on the cartridge, inhale and enjoy.

Charging

Once you start using your Suncig cigarette you will notice the LED tip light-up each time you inhale. When your battery starts to run low the LED will begin to flash continuously.

To charge your Suncig cigarette (battery) unscrew your cartridge and attach your battery to the USB charger, plug your USB into the usb wall charger or a powered-up computer to charge.

The tip (led) of your Suncig will illuminate while charging. When the LED goes out your battery is fully charged, unscrew the USB and screw the cartridge back on and continue vaping! (charging may take up to 3 - 4hours)

Cartridges

When your flavor cartridge produces less vapor and/or the taste changes to a burnt taste it is time to replace the cartridge with a new one.

Portable Charger Case (PCC)

Your Suncig PCC can re-charge your battery 3 to 4 times before the case itself needs to be re-charged.

To charge your Suncig PCC plug the provided cable into the bottom of the PCC and plug it into your wall charger or computer.

(do not leave a battery screwed into the PCC case while charging the case)

To re-charge your Suncig battery inside the PCC simply screw it all the way into the front battery slot. You will notice the tip of the battery light up indicating the battery is charging.

Information and Trouble shooting

Each Suncig cartridge should last around 200 to 250 puffs (will depend on the length of each puff).

If your cartridge is new and produces no vapor it maybe faulty, in this case please contact us: info@suncig.com

Web:

International www.suncig.com

Australia www.suncig.com.au

Germany www.suncig.de